

Clean-up and Maintenance:

Cubicle Track, Curtains, and Soft Goods

Cubicle Tracks

Cubicle tracks require very little maintenance. If carriers do not move smoothly, check the track for binding. If the track is clear of debris, spray the inside of the track with a light coating of silicone spray. Be careful not to spray the curtains and wipe any excess spray from the track.

Standard Cubicle Curtains, Cubicle Curtain Mesh or Standard Fabric Only

1. Wash Cycle: Wash as any standard colored fabric, with water temperature not to exceed 160°F. Detergents: Use a synthetic detergent. DO NOT use a caustic soap or bleach. Do Not add softener.
2. Extraction Cycle: Fabric requires no more than 2-4 minutes extracting, depending on size of load and equipment used.
3. Drying Cycle: Tumble dry for 3-5 minutes on the low/synthetic cycle. DO NOT overload the dryer. Excessive heat will decrease the permanent press feature of this fabric. Remove immediately from the dryer after the cycle is complete.
4. DO NOT put through a mangler.